

Lab meeting

Line Detection in Thermal Images

Contents

- Drone
- Line Detection (in thermal images)
- Super-Resolution
- Results
- Conclusion
- Future Tasks

Drone

[DJI Matrice 4T]



[Spec]

- Wide Camera
- Tele Camera
- Infrared Thermal Camera
- RTK module
- Intelligent Operations with AI

[DJI Mavic 3T]



[Spec]

- Wide Camera
- Tele Camera
- Infrared Thermal Camera
- RTK module

Drone

[DJI Matrice 4T]



[DJI Mavic 3T]



Due to arrival time issues...

Drone

[DJI Matrice 4T]

Resolution	DJI Matrice 4T: 640 × 512
Pixel Pitch	DJI Matrice 4T: 12 μm
Frame Rate	DJI Matrice 4T: 30 Hz
Lens	DJI Matrice 4T DFOV: 45°±0.3° DJI Matrice 4T equivalent focal length: 53 mm DJI Matrice 4T Aperture: f/1.0 DJI Matrice 4T Focus: 5 m to ∞
Sensitivity	DJI Matrice 4T: ≤50mk@F1.0
Temperature Measurement Method	DJI Matrice 4T: Spot Meter, Area Measurement
Temperature Measurement Range	DJI Matrice 4T: High Gain Mode: -20°C to 150°C (-4°F to 302°F) () Low Gain Mode: 0°C to 550°C (32°F to 1022°F)
Palette	DJI Matrice 4T: White Hot/Black Hot/Tint/Iron Red/Hot Iron/Arctic/Medical/Fulgurite/Rainbow 1/Rain
Photo Format	DJI Matrice 4T: JPEG (8bit), R-JPEG (16bit)
Video Resolution	DJI Matrice 4T: 1280 × 1024@30fps (Super Resolution enabled, Night Mode not activated) Other conditions: 640 × 512@30fps

[DJI Mavic 3T]

Pixel Pitch	12 μm
Frame Rate	30 Hz
Lens	DFOV: 61° Format Equivalent: 40 mm Aperture: f/1.0 Focus: 5 m to ∞
Noise Equivalent Temperature Difference (NETD)	≤50 mK@F1.0
Temperature Measurement Method	Spot Meter, Area Measurement
Temperature Measurement Range	-20° to 150° C (-4° to 302° F, High Gain Mode) 0° to 500° C (32° to 932° F, Low Gain Mode)
Palette	White Hot/Black Hot/Tint/Iron Red/Hot Iron/Arctic/Medical/Fulgurite/Rainbow 1/Rain
Photo Format	JPEG (8-bit) R-JPEG (16-bit)
Video Resolution	640×512@30fps
Bitrate	6 Mbps

➔how about using **Super-Resolution?**

Base Line

- Used LSD
- Used Super-Resolution for Infrared Image (PSRGAN)

*Progressive Super-resolution Generative Adversarial Network

LSD: a Line Segment Detector

Rafael Grompone von Gioi¹, Jérémie Jakubowicz², Jean-Michel Morel³,
Gregory Randall⁴

¹CMLA, ENS Cachan, France (grompone@cmla.ens-cachan.fr)

²TELECOM ParisTech, France (jakubowi@telecom-paristech.fr)

³CMLA, ENS Cachan, France (morel@cmla.ens-cachan.fr)

⁴IIE, UdelAR, Uruguay (randall@fing.edu.uy)

Communicated by Lionel Moisan Demo edited by Rafael Grompone

982



IEEE SIGNAL PROCESSING LETTERS, VOL. 28, 2021

Infrared Image Super-Resolution via Transfer Learning and PSRGAN

Yongsong Huang[✉], Zetao Jiang, Rushi Lan[✉], Shaoqin Zhang, and Kui Pi



Line Detection

- Used LSD



Super-Resolution


- Used SR(ie.Super-Resolution) for Infrared Image





Results #1_Original



Results #1_Clahe



Results #1_SR





Results #1_Discussion

- Changed 2 parameters
 - Scale 0.8→0.6
 - Quant 2.0→0.5


```
# 파라미터 직접 지정
lsd = cv2.createLineSegmentDetector(
    refine=cv2.LSD_REFINE_NONE, # 후처리 x
    scale=0.8,                  # 스케일링 비율
    sigma_scale=0.6,           # 가우시안 블러 정도
    quant=2.0,                  # 윤곽선 양자화 파라미터
    ang_th=22.5,                # 각도 차 임계값
    log_eps=0,                  # 로그 eps 파라미터
    density_th=0.7,             # 밀도 임계값
    n_bins=1024                 # 히스토그램 bin 갯수
)

lsd = cv2.createLineSegmentDetector(
    refine=cv2.LSD_REFINE_NONE, # 후처리 x
    scale=0.6,                  # 스케일링 비율
    sigma_scale=0.6,           # 가우시안 블러 정도
    quant=0.5,                  # 윤곽선 양자화 파라미터
    ang_th=22.5,                # 각도 차 임계값
    log_eps=0,                  # 로그 eps 파라미터
    density_th=0.7,             # 밀도 임계값
    n_bins=1024                 # 히스토그램 bin 갯수
)
```


Results #1_SR(Changed)




Results #1_Clahe(Changed)



Results #2_Original



Results #2_Clahe



Results #2_SR (Changed)



Conclusion

- Using SR




→
x2




Conclusion


- Comparing 3-results



[SR+LSD_(changed)]




[SR+CL_(ie.CLAHE)+LSD]




[CL+LSD]

Conclusion

- SR+LSD is the most!!



[SR+LSD_(changed)]



[SR+CL_(ie.CLAHE)+LSD]



[CL+LSD]

Future Tasks

- Construct Indoor-Dataset with Drone
- Changing a Parameter (for Improved Pre-processing Results)
- Line-Mapping using Thermal Image

Thank You
for Listening