


Lab meeting

Line Detecting & Tracking in Thermal Images



Contents

- LSD
- M-LSD
- HAWP
- SOLD2
- Future Tasks




LSD

- Without changing any parameters





M-LSD

- Towards Light-weight and Real-time Line Segment Detection (2021)



HAWP

- Holistically-Attracted Wireframe Parsing (2020)



SOLD2

- Self-supervised Occlusion-aware Line Description and Detection (2021)
- Input: gray-scale img/ Output: J, H, D
- Robust to **occlusion** (descriptor)



SOLD2

Lines	Desc	Wireframe [18]		ETH3D [49]	
		Precision↑	Recall↑	Precision↑	Recall↑
LSD [57]	LBD [65]	0.496	0.597	0.132	0.376
	LLD [55]	0.123	0.116	0.085	0.230
	WLD [24]	0.528	0.804	0.127	0.398
	SOLD ² (Ours)	0.591	0.889	0.159	0.525
Ours	SOLD ² (Ours)	0.882	0.688	0.196	0.538
Ours w/ NMS	SOLD ² (Ours)	0.777	0.949	0.190	0.688








Figure 7: **Line matches visualization.** Comparison of line matches between LSD [57] + WLD [24] and our method with **correct** matches, **incorrect** ones, and **unmatched** lines. SOLD² provides fewer but more repeatable lines that can be matched in poorly textured areas and with repetitive patterns.

SOLD2





SOLD2 (occlusion)





SOLD2 +Clahe



- Almost same with Original SOLD2



SOLD2 + Unsharp mask




SOLD2 + Unsharp mask



SOLD2 (matching)

frame_0892.png- matched lines




frame_0896.png- matched lines




SOLD2 (matching)

frame_1054.png- matched lines




frame_1059.png- matched lines




SOLD2 (matching)

frame_0179.png- matched lines






frame_0187.png- matched lines




SOLD2 (training)

- Can't recognize line in the thermal image







LSD




M-LSD




HAWP



SOLD2



Clahe



Sharpen

Future Tasks

- Using **SOLD2** and Training with own dataset (using DJI Mavic 3T)
- Making artificial environment with distinct thermal divisions
- Training with patterned 16-bit images




Fig. 3: Checkerboard Thermal Image



Training your own model

All training parameters are located in configuration files in the folder `config`. Training SOLD² from scratch requires several steps, some of which taking several days, depending on the size of your dataset.

- ▶ Step 1: Train on a synthetic dataset
- ▶ Step 2: Export the raw pseudo ground truth on the Wireframe dataset with homography adaptation
- ▶ Step3: Compute the ground truth line segments from the raw data
- ▶ Step 4: Train the detector on the Wireframe dataset
- ▶ Step 5: Train the full pipeline on the Wireframe dataset

Future Tasks

- Using **SOLD2** and Training with own dataset (using DJI Mavic 3T)
- Making artificial environment with distinct thermal divisions
- Training with patterned 16-bit images



Thank You
for Listening